



HARD SURFACE

Wood Re-Coating

INTRODUCTION

Bridgepoint's Wood System is designed for re-coating floors with an existing Urethane finish. It is not designed to repair the wood surface, but will add life to the existing Urethane finish. A hardwood floor can last for two or three generations but will only take, on average, three sandings. This means that re-coating several times between sandings will allow the wood floor to last much longer.

PROCEDURE

- **STEP 1**
Inspect the floor for damage to the wood and the existing finish. Also check for wax coatings. **Bridgepoint Wood Finish** will not adhere to wax.
- **STEP 2**
Vacuum the floor to remove dry soil.
- **STEP 3**
Mist the floor with **Wood Cleaner** and mop off with **Bridgepoint Applicator** and fitted **Terry Cloth Towel**.
- **STEP 4**
Fill in obvious gaps between boards with **Wood Patch**. Dry with hair dryer.
- **STEP 5**
Mist **Wood Cleaner** along edges of the floor and scrub with small cut off sections of **Maroon Pad**. Wipe off soil as you go with **Terry Cloth Towel**.
- **STEP 6**
Apply a light amount of **Wood Cleaner** to a small section of the floor (10x10) and clean with **Maroon Pad** and **Rotary Machine**. Wipe up residue as you go with **Bridgepoint Applicator** and fitted **Terry Cloth Towel**.
- **STEP 7**
Apply another application of **Wood Cleaner** and clean with **Microfiber Bonnet** and **Rotary Machine**. Allow floor to dry thoroughly. Do not use airmover. This will prevent the spread of dust to clean areas.

- **STEP 8**
Put on gloves and apply a coat of **Bridgepoint Wood Finish** to edges with soft cloth.
- **STEP 9**
Place clean, fitted **Terry Cloth Towel** to **Bridgepoint Applicator**. Apply **Wood Finish** in small sections at a time by pouring on floor and distributing evenly with applicator. Allow to dry for approximately one hour between coats of finish.
- **STEP 10**
Apply second coat in same manner as first. Floors in poor shape may need a third coat.
- **STEP 11**
Light foot traffic is possible in socks after a few hours. Furniture can be replaced in 24 hours. Most of the curing is complete in 48 hours.

Chemicals Needed



Bridgepoint Wood Cleaner
Type: Hardwood Cleaner
Highlights: A one-step cleaner that removes surface soil and embedded dirt.



Bridgepoint Wood Finish, Semi-Gloss or Matte
Description: Hardwood Gloss and Matte
Purpose: Hard polyurethral finish - gives a serious gloss or matte shine to the floor.



Wood Patch
Description: Wood Patch
Purpose: Repairs scrapes and gouges.

Accessories Needed



Maroon Pad
Description: Scrub Pad
Purpose: Removes light scratches and soil build-up.



White Polishing Pad
Description: Buffing pad
Purpose: Acts as a cushion between Maroon Pad and Rotary Machine.



Applicator w/ Terry Cloth Cover
Description: Chemical applicator
Purpose: To clean wood floors and apply finish.



Micro-Fiber Bonnet
Description: Bonnet
Purpose: Great for use with the rotary machine to clean hardwood floors.



Air King
Description: High volume air mover
Purpose: Aids in rapid drying.



Soft Cloth
Description: Lint-free cloth
Purpose: Used for applying to edges and to vertical surfaces such as cabinets or railings.

Equipment Needed



Rotary Machine
Description: Rotational scrubbing and buffing
Purpose: Uses circular motion to clean and buff hardwood floors.

HELPFUL HINTS – You can clean the wood between coatings by using the **Wood Cleaner** with **Microfiber Bonnet** and **Rotary Machine**. After the floor is dry, you can increase the shine of the finish by buffing with a **White Pad** and **Rotary Machine**.



CAUTION – Do not allow a lot of moisture to absorb between the boards. Do not apply any **Wood Finish** over paste waxed finish.



Quick Guide



PROCEDURE

- 1 Inspect floor for damage to wood, finish and presence of paste wax.
- 2 Vacuum dry soil off wood surface.
- 3 Clean with **Wood Cleaner** and **Bridgepoint Applicator** and fitted **Terry Cloth Towel**.
- 4 Apply **Wood Patch** where necessary. Dry with hair dryer.
- 5 Clean edges and open areas with **Wood Cleaner** and **Maroon Pad** by hand or rotary machine.
- 6 Clean floor again with **Wood Cleaner** and **Microfiber Bonnet** and rotary machine.
- 7 Apply **Wood Finish** to edges and open areas with soft cloth or **Bridgepoint Applicator** with fitted **Terry Cloth Towel**. Allow to dry for approximately one hour.
- 8 Apply second coat in same manner as first coat. Apply third coat, if needed, in the same way.

PRODUCTS NEEDED

- **Bridgepoint Wood Cleaner**
- **Bridgepoint Wood Finish, Semi-Gloss or Matte**
- **Wood Patch**
- **Maroon Pad**
- **White Pad**
- **Bridgepoint Applicator**
- **Fitted Terry Cloth Towels**
- **Microfiber Bonnet**
- **Air King**
- **Soft Cloth**
- **Rotary Machine**

Other Resources

**Bridgepoint Oriental Rug Cleaning
Manual and Course**

www.InterlinkSupply.com

To locate your nearest Interlink Supply

Call 1-800-660-5803